

IFB 2128 EXHIBIT 2 - WORK AREA DETAIL



Existing exterior door and trench drain. Clean accumulated debris from area and install new overlay to avoid increasing water flow to this corner.

Existing concrete curb and gutter. Avoid blocking existing drain pipes that discharge through curb.

Existing D.I. - Slope new work to drain to this location.

Existing concrete sidewalk. Surface of new overlay shall not be higher than sidewalk surface.

Existing concrete sidewalk with asphalt overlay. See scope of work in IFB. Remove asphalt overlay and loose concrete. Prepare for new minimal overlay.

General location of Severe Rutting. Remove and replace approximately 240 SF of unsuitable subgrade with 21A / 21B stone

Saw cut existing asphalt and remove approximately 240 SF of existing sidewalk and curb to provide smooth transition to access road. Undercut and install new 21A / 21B as necessary for new asphalt application.